

Prepare the tools and replacing material code (B9300932)



Loosen the Signal cord, Disassemble the control box, use handy Tool to Disassemble





Unfix the air valve, deflating, unscrew the connection parts, take out the control box




Get rid of the foam, top cover and center shell



Change the new PTC heater, pin according to the tab sign., insert the box and screw the baffle well.



Unpin the connection wire tab, take out the PTC heater



Cut down the 4pcs clips, and disassemble the baffle, take out the power board



Fix and screw the the foam, top cover and center shell



Put the control box into spa pool and connect the parts well



Screw the inlet and outlet, fix the control panel, connect the signal



Fix the air valve and re-start to inflate

