


How to replace connection parts

Material code: B9301085

Prepare the tools and replacing material code (D0102532)



Open the product and remove the foam from drain pipe and transparent pipe. , take out the



Unscrew the nut and use the screw-driver to take out the circle of snake



Use the air blower to heater the transparent pipe, and use screw-driver to take out the connection parts.



Assemble and screw the circle of snake, assemble the checking valves and screws well



Use the old parts press the new parts and assemble into transparent pipe. (Make sure assembling to the bottom of the new connection parts)



Take out the seal ring from the old connection parts, then assemble the new parts , screws

