

Mercedes-Benz AMG R/C Children Car Manual

- Forward ● Backward
- Turn right ● Turn left
- Stop ● Light



Product Size: 132*66*60 CM

WARNING :Not to be used in traffic

This product is designed for children age 3+.

Original License Counterfeit Investigated

The company has passed the ISO 9001:2008 quality management system certification. Execute standard: GB6675 GB19865

I. WHEEL INSTALLATION

Install left and right front wheels:

1. Put one gasket on the front axle. (according to the first photo on the right side)
2. Let the front axle through the training wheel. (according to the first photo)
3. Put another gasket on the front axle. after the training wheel. (according to the photo)
4. Fix the nut on the axle. (according to the second photo)
5. Put the small wheel cover on the wheel. (according to the third photo)
6. The other side is the same step.



The rear wheel installation instructions

1. Put the motor part of the right gearbox into the hole of the car body, fix the right gearbox by one screw, the left gearbox fix as the same way.
Remark: before fix the rear wheels, must fix the drive wheel gear by the screw.
2. Fix the gear cover by the screw, as the left photo.



3. Let the rear axle through the driving wheel. Make the driving part of gear into the gearbox. (according to the first photo on the right side)
4. Put one gasket on the rear axle. after the driving wheel. (according to the photo)
5. Fix the nut on the rear axle with the plastic spanner. (according to the second photo)
6. Put the small wheel cover on the wheel in turn. (according to the fourth photo)
7. The other side is the same step.



II. Turn the vehicle over and fix the side, front and rear supports using the screws provided.



right and left parts are the same.

front

rear

III. STEERING WHEEL INSTALLATION

Remove the nut and bolt from the steering wheel. Firmly connect the wires from the steering wheel to the wires from the dashboard. Push the steering wheel onto the steering column, align the holes and lock in place using the nut and bolt.



IV. BATTERY CONNECTION



Please connect the red and black wires below the bonnet to the corresponding battery terminals. It is advised to test the main functions of the car once the battery has been connected before full assembly is completed.

V. FRONT WINDSHIELD INSTALLATION

Align the holes in the car body with the clips on the windshield and push down until they click fully into place.



VI. CAR SEAT INSTALLATION



Remove the two screws and place the seat into position as shown. Reinsert the screws to fix the seat in place.

VII. CAR BONNET INSTALLATION

Please ensure the connections below the bonnet are connected and in good order. Align the bonnet lugs with the car lugs and push into place. This will be a tight fit when pushing the bonnet over the 2 raised lugs on the car. Fit the 2 screws to the lugs to hold in place.



VIII. Spare Wheel Installation



Fix the spare wheel with 2 large flat head screws.

DISPOSAL OF BATTERY

Disposal of Battery

- Your sealed lead-acid battery must be recycled or disposed of in an environmentally sound manner.
- Do not dispose of your lead-acid battery in a fire. The battery may explode or leak.
- Do not dispose of lead-acid battery in your regular household trash. The incineration land filling or mixing of sealed lead-acid batteries with household trash is prohibited by law.
- Return an exhausted battery to your local approved lead-acid battery recycle. Such as a local seller of automotive batteries.
- Contact your local waste management officials for other information regarding the environmentally sound recycling and disposal of lead-acid batteries.

■ CHARGING PRECAUTIONS

Battery polarity can not be reversed, please ensure the red wire is connected to the red battery terminal and the black wire is connected to the black battery terminal.

- Press the power switch to OFF position to turn the power off.
- Open the seat, connect the battery plug, red to red.
- Never drain battery completely or to a crawling speed, recharge the battery when a decrease in speed and power is noticed warranty will be voided if misuse has occurred.
- Battery charging must be done by adults only. Never allow children to charge the battery. A child could be injured by the electricity involved in charging the battery.
- Please don't connect the wires to a short circuit.
- The charger and the battery are not a toy. Do not allow children to play with the charger and the battery.
- Only operate the battery and charger specified according to the manual instructions.
- Please don't open the battery and the charger.
- Always secure the battery with the bracket. Or battery can be fall out and injure children if vehicle tips over.
- The battery must be handled and operated by adults only. The battery is heavy and contains sulfuric acid (electrolyte). Dropping the battery could result in serious injury.
- Before charging the battery check if wear or damage to the battery, charger, the connectors and other parts. Any damage is found, the charger should be repaired or replaced immediately. Do not use a damaged charger.
- It is normal for the adaptor to feel warm during charging, but if the charger feels too hot, stop charging right now and check the battery and adaptor.

When charging turn of the power switch.

Please charge the battery for 8-10 hours after first use.

Subsequent charges should be 6-8 hours but not exceeding 10 hours.

If not being used batteries should still be charged at least once a month to keep the cells active.

1. Open the cover of charging socket on the car.
2. Plug the charge into the charging socket.
3. Plug the other end of the charger into your wall socket.

Batteries are perishable items that are subject to under and overcharging, please observe the charging times



Implementation of national standards: EN71, EN62115, CE, ROHS



*Mercedes-Benz AMG G55 and the design of the enclosed product are subject to intellectual property protection owned by Daimler AG. They are used by Jiaxing Dongma Baby Carrier Co., Ltd. Under license. License: Jiaxing Dongma Baby Carrier Co., Ltd.


■ TROUBLESHOOTING

Problem: The car will not move

Answer 1: Please make sure the charger has been removed from the car charging point.

Answer 2: The battery is low on charge. Please charge for 6-8 hours but not exceeding 10 hours.

Charge at least once a month to keep the cells active



To avoid fuse cut off the power:

1. Max: 30kg, overload is forbidden
2. Do not drag any item behind this product.
3. Do not allow water or other liquids dip the electrical parts.
4. Do not change the line system by yourself.

Answer 3: The battery wires are not connected. Please check the connections on the battery terminals are firmly in place.

Answer 4: battery is broken

Please contact the agent or manufacturer

Answer 5: car body wiring has been damaged

Please contact the agent or manufacturer

Answer 6: the motor is damaged

Please contact the agent or manufacturer

Problem: unable to charge

Answer 1: The battery wires not connected. Please check

the connections on the battery terminals are firmly in place.

Answer 2: The charger is not inserted in place

Make sure the charger is plugged into the power outlet properly

(ensure the power outlet switch turn on)

Answer 3: The charger not working correctly. The charger should feel slightly warm when on charge. Please contact the agent or manufacturer.

■ TROUBLESHOOTING

Problem: The car only runs for a short time

Answer 1: The battery is low on charge. Please charge for 6-8 hours

but not exceeding 10 hours

Charge at least once a month to keep the active.

Answer 2: Battery ageing

The battery may need to be replaced depending on its charging history and age.

Problem: The sounds do not work.

Please ensure the volume is turned up and the MP3 lead is not connected.

The steering wheel sounds will not work when the MP3 is plugged into the car.

Problem: Charger makes a buzzing sound while charging

This is normal.

Problem: Charger overheating

It is normal for the battery and charger to warm slightly during

charging. If they feel excessively hot then please

check for a current overload or battery short circuit.

WARNING: Vehicle must be charged fully before use.

Please read manual carefully before use.

Adult assembly required.

This toy have no brake

Not to be used in traffic.

Always wear a helmet and protective

clothing when riding. Continuous adult supervision

required when using this product.

Charging the battery can only be done by adult at all times.

Please keep the manual and packaging for future

reference as it contains important information.

The instructions for use should bear a reminder that

the toy should be used with caution since skill

is required to avoid falls or collisions causing injury

to the user or third parties.

■ SAFETY PRECAUTIONS

01. While riding, adult supervision is required all the time.

02. Always wear a helmet when driving.

03. Please don't drive near road or on the footpath.

04. It is not recommended to drive the vehicle on wet surface or on slope greater than 15-degree.

05. It is recommended to drive this vehicle on smooth surface only.

06. Please don't driving this vehicle outdoors when it is raining.

07. Make sure that the vehicle stop completely before changing direction from forward to reverse.

08. Please don't allow children to operate the charger or play with the battery

09. Clean the vehicle with a dry cloth only.

10. Please follow the correct weight and age limits allowed to drive this vehicle.

11. It is prohibited to change the circuit or add other electric parts.

12. Adults must teach their children about safe driving procedures.

13. Please turn the power off when not in use.

14. Check the seat to ensure it has been fitted and secured with a bolt before driving.

15. Inspect all wires and connections of the vehicle periodically.

16. Charging the battery should only be done by adults.

17. Charging plug is located underneath the seat.

18. In order to avoid accidents, please ensure the vehicle is safe before driving.


19. Please don't let any child touch the wheels or be near them when the car is moving.

20. Warranty period is 90 days from the date of purchase.

21. Proof of purchase must be given for goods to be returned, repaired or replaced.

USING INSTRUCTION

Key start as real car, insert the key and turn it on.



1. Press the music button on the steering wheel for horn or music.
2. Attach the MP3 lead to your device to play or own music through the car.

Please note the steering wheel sounds wheel not work when the MP3 lead is connected.

How to use the remote control

Press the power switch to OFF position to turn the power off.

Take off the battery cover screw, open the battery cover.

Put two AA 1.5V remote control battery on.

Press the power switch to ON position.

Battery charging must be done by adults only.

The remote control must be handled and operated by adults only.

non-rechargeable batteries are not to be recharged.

different type of batteries or new and used batteries are not to be mixed

batteries are to be inserted with the correct polarity.

exhausted batteries are to be removed from the toy.

rechargeable batteries are only to be charged under adult supervision.

rechargeable batteries are to be removed from the toy before being charged

REMOTE CONTROL INSTRUCTIONS

Forward & Backward

R/C indicator light



Turn left and turn

right switch

Keep remote control away from children as it is for parental use only.